



**Stanford Research Systems, Inc.**  
290 C Reamwood Avenue, Sunnyvale, CA 94089, U.S.A.  
Phone: 408-744-9040 FAX: 408-744-9049  
Email: [janied@thinkSRS.com](mailto:janied@thinkSRS.com) .. Website: [www.thinkSRS.com](http://www.thinkSRS.com)

---

***Volatility Statement for SRS FS725 (Benchtop Rb. Freq. Std.)***

The FS725 contains various types of memories, as listed below:

**Non-Volatile Memory:**

20 KB EPROM	Not user modifiable; contains instrument's firmware
512 Bytes EEPROM	User modifiable; contains instrument settings

To clear:  
Send command "RC1"

**Volatile Memory:**

768 Bytes SRAM	User modifiable; used for operation and user settings
----------------	---

To clear:  
Send command "RS1"

Please feel free to contact SRS should you have any further questions.